
CoiNel

DYNO-MINI
Quick Start Guide



Getting Started with DYNO-MINI

Portable Bluetooth Thermal Printer


Compact • Wireless • Reliable

www.coineltech.m

BEFORE FIRST USE


1. Remove the battery cover.
2. Pull out the insulating sticker from the left side of the battery.
3. Reinstall the battery cover.
4. Fully charge the printer before first use.
5. Power on the printer.

Note: The printer will not turn on until the battery insulating sticker is removed.




1. Charging the Printer

a. Connect the USB Type-C end of the cable to the printer's USB Type-C port.
b. Connect the USB Type-A end of the cable to a computer, power adapter, or any compatible USB power source.
c. Allow the printer to fully charge before first use.



A. LED Indicators


- **Green LED - Charging and power indication.**
  - During charging, the LED remains blinking.
  - When the device is powered ON, the LED remains continuously ON.
- **Blue LED - Indicates Bluetooth connection status.**
  - o LED ON: Bluetooth connected
  - o LED OFF: Bluetooth disconnected
- **Red LED - Indicates error conditions such as paper out or overheating.**




❶ ERROR
❷ CHARGE
❸ STATUS

2. Loading the Thermal Paper


1. Open the printer cover.




2. Insert the thermal paper roll correctly.




3. Pull a small portion of paper outward.



4. Close the cover securely.



5. Press the *FEED* button to check paper movement.(optional)




A. Supported Paper Size

- Paper Width: 55mm – 57mm
- Max Roll Diameter: 30mm

3. Power ON/OFF


- Press and hold the POWER button for 2–3 seconds to turn ON/OFF the printer.



4. Test print

- Turn on printer
- Press and hold the Feed button until the test print is generated.
- Release the Feed button after the test print is generated.





5. Bluetooth Connection

1. Turn ON the printer.
2. Enable Bluetooth on your mobile device.
3. Search for available devices.
4. Select “Bluetooth name given in test print” from the list.
5. Once connected, the Blue LED will indicate Bluetooth status.

6. Important Features

- Portable & Lightweight Design
- Bluetooth + USB Connectivity
- Rechargeable 2600mAh Battery
- ESC/POS Compatible
- Auto Overheat Protection
- Paper-Out Alarm

7. Safety & Usage Tips

- Use only compatible thermal paper.
- Keep the printer away from water and excessive heat.
- Charge regularly for optimal battery life.
- Avoid pulling paper forcefully during printing.

Address: 77/9 1st and 2nd Floor 4th Cross, 9th Main Rd, Vijaya Nagar II Stage, Hampi Nagar, Bengaluru, Karnataka 560104

E-mail: support@coineltech.com

Distributor

MITRONIC
SALES PRIVATE LIMITED

+91 99721 32037 | +91 87108 84899

www.mitronic-sales.com